



INDUSTREX Films for Industrial X-ray Use - Product Guide¹

				Replaces		Available Formats (code)							Spectral	Safelight	AUTOMATIC Processing Chemicals ³	
INDUSTREX Film / Product Code	System Class ²					Sheets				Rolls						Recommended
	ASTM E1815	ISO 11699-1 EN 1SO 11699-1	Notched	AGFA	FUJI	Non-interleaved (1)	Interleaved (5)	READY-PACK II (2)	PB Contactpak (7)	NIF Rolls (bulk) (359)	Lead Pack (382)	Ready Pack (381)	Sensitivity	Filter	Developer Fixer	Starting Points
DR50 / 6536	Special	C1	✓	D2	IX25	~										AUTOMATIC 8 minute cycle Developer Time and
M100 / 5532	Class 1	C2	✓	D3	IX50	√		√	✓	√	√	√	X-ray and visible blue light	(Red) 1, 2 or GBX-2	DEVELOPER INDUSTREX Single Part Developer Replenisher, mixed 1:3 w/H ₂ 0 Replenishment Rate: 665 mL/m ² FIXER INDUSTREX LO Fixer and Replenisher, mixed 1:3 w/H ₂ 0 Replenishment Rate: ⁴	Temperature: 100 seconds @ 26° C (79°F)
MX125 / 4748	Class 1	C3		D4	IX50	✓	✓	✓	✓	✓	√	✓				5 minute cycle Development Time and Temperature:
T200 / 6537	Class 1	C4	✓	D5	IX80	✓	✓			✓	√					$60 \text{ seconds } @ 30^{\circ} \text{ C}$ (86° F)
AA400 / 5533	Class 2	C5	✓	D7	IX100	✓	√	✓	✓	√	√	√				MANUAL⁶ Development Time and Temperature:
HS800 ⁵ /5747	-		✓	D8/ F8	IX150	~			✓	✓					1200 mL/m ²	4 minutes @ 22° C (72° F)

¹ Please refer to the NDT Resources at www.carestream.com for film and chemistry technical data.

³ Automatic

INDUSTREX Single Part Developer Replenisher to make 40L, CAT No. 531 5288 INDUSTREX Single Part Developer Starter to make 19L, CAT No. 835 1413 INDUSTREX LO Fixer and Replenisher to make 40L, CAT No. 515 9082

Manual

INDUSTREX Manual Developer Kit to make 40L, CAT No. 105 7009

 $\hbox{- Kit contains 2 five-liter bottles of developer, 2 one-liter bottles of developer and 2 bottles of stop bath.}\\$

INDUSTREX Manual Fixer Kit to make 40L, CAT No. 105 7017

- Kit contains 2 five-liter bottles of fixer, 2 one-liter bottles of fixer and 2 bottles of rinse solution. Sold separately as

INDUSTREX Manual Developer to make 40L, CAT No. 532 0635

INDUSTREX Manual Fixer to make 40L, Cat No. 532 0643

INDUSTREX Manual Stop Bath to make 40L, CAT No. 105 4873

INDUSTREX Manual Rinse Solution to make 40L, CAT No. 105 7025

© Carestream Health, Inc., 2015 Created in the USA P/N 9J8961 Carestream Health 150 Verona Street Rochester, NY 14608 USA

2015-10-02

INDUSTREX and READY-PACK II are trademarks of Carestream Health.

² Classification applies to INDUSTREX films processed in INDUSTREX chemicals, not the other manufacturer's product they are replacing.

⁴ For optimum archivability, such as required for nuclear applications, a 10 % increase in fixer replenishment rate may be desirable. For more information, consult TI-6K7080 INDUSTREX Films Technical Data.

⁵ HS800 displays high speed and contrast throughout an extended range of optical densities when used with fluorescent and fluorometallic screens. HS800 is recommended for use with LANEX Fast Screens, CAT No. 116 0688.

⁶ Eliminate guesswork in determining the proper exposure and get more consistent results by using the INDUSTREX Ir192 Film Exposure Calculator available through your regional Carestream NDT sales manager.